



Photron's high-speed camera captures a 40 mile per hour vehicle impact test. All vehicles are subjected to rigorous crash and sled tests, every one of which must be recorded at 1,000 frames per second for the engineers to analyze to see how the vehicle and dummy occupants interact. These images are selected from the original 1,000 fps recording.

# 1024 PCI

FASTCAM-X

## Mega pixel resolution at 1,000 frames per second for the personal computer.

The FASTCAM-X 1024 PCI from Photron is the world's first PC-based high-speed imaging system to provide 1,000 frames per second (fps) recording at full mega pixel image resolution.

Utilizing the same super light sensitive 10-bit CMOS sensor as the Ultima APX with large 17 micron square pixels, the 1024 PCI operates from 60 to 1,000 fps at full 1,024 x 1,024-pixels resolution, and at reduced resolution all the way to a top speed of 109,500 fps.

A global electronic shutter, operating down to 1.5 microseconds ensures even the fastest moving objects are frozen, blur free, in every image.

A user selectable 'Region Of Interest' function enables the active image area to be defined in steps of 128 pixels wide by 16 pixels high to allow the most efficient use of frame rate, image resolution and memory capacity for any event. Up to 20 commonly used configurations can be saved to memory for future operation.

A single flexible sixteen foot (5 meter) cable allows the lightweight camera head easy access to any location.

### BENEFITS

Variable speed resolutions, including:

1,024 x 1,024-pixels at 1,000 fps

512 x 512-pixels at 3,000 fps

27,000 fps at 128 x 128-pixels

109,500 fps at reduced resolution

Global shuttering to 2 $\mu$ s, independent frame rate selected

Expandable memory offers several different configurations (PCI card and memory daughter PCB still fit in a single PCI slot) providing a wide range of record times:

2GB for 1.6 seconds at 1,000 fps full resolution

4GB for 3.08 seconds at 1,000 fps full resolution

6GB for 4.6 seconds at 1,000 fps full resolution

8GB for 6.2 seconds at 1,000 fps full resolution

12GB for 9.2 seconds at 1,000 fps full resolution

16GB for 12.3 seconds at 1,000 fps full resolution

24GB for 18.5 seconds at 1,000 fps full resolution

Fits in single PCI slot, regardless of memory configuration selected

Camera is connected to PCI card via 16 foot (5m) flexible cable

User defined 'Region Of Interest'



## SLOW MOTION IMAGING SOLUTIONS

# Photron®

[www.photron.com](http://www.photron.com)  
[image@photron.com](mailto:image@photron.com)

## SPECIFICATIONS

Frame Rate (fps)	Max. Resolution		Record Time (seconds)				Record Time (frames)			
	Horizontal	Vertical	2GB	4GB	8GB	12GB	2GB	4GB	8GB	12GB
60 to 1,000	1,024	1,024	1.54	3.20	6.40	9.60	1,536	3,200	6,400	9,600
2,000	1,024	512	1.60	3.20	6.40	9.60	3,200	6,400	12,800	19,200
3,000	512	512	2.13	4.35	8.70	13.06	6,400	13,056	26,112	39,168
6,000	512	256	2.13	4.35	8.70	13.06	12,800	26,112	52,224	78,336
10,000	256	256	2.61	5.22	10.44	15.67	26,112	52,224	104,448	156,672
18,000	256	128	2.90	5.80	11.61	17.41	52,224	104,448	208,896	313,344
27,000	128	128	3.87	7.74	15.47	23.21	104,448	208,896	417,792	626,688
45,000	128	64	4.64	9.28	18.57	27.85	208,896	417,792	835,584	1,253,376
73,000	128	32	5.72	11.45	22.89	34.34	417,792	835,584	1,671,168	2,506,752
109,500	128	16	7.63	15.26	30.52	45.79	835,584	1,671,168	3,342,336	5,013,504

### Sensor

CMOS (Bayer system color, single sensor) with 17µm pixel

### Shutter

Global electronic shutter from 16.7ms to 1.5µs independent of frame rate

### Extended Dynamic Range

Four presets prevent pixel over-exposure

### Saved Image Formats

JPEG, AVI, TIFF, BMP, RAW (compressed or uncompressed) PNG (10-bit), and FTIF (10-bit). Images can be saved with or without image or comment data

### Memory

Currently four options available: 2GB, 4GB, 8GB and 12GB. (16GB and 24GB options are planned)

### Resolution

In addition to pre-selected resolutions, twenty memory slots are available for users to store custom frame rate and resolution combinations conforming to the 128 pixels wide by 16 pixels high pattern

### Phase Lock

Enables cameras to be synchronized precisely together to a master camera or external source

### Triggering

Positive TTL 5Vp-p or switch closure

### Lens Mount

Interchangeable F-mount and C-mount using supplied adapters

### Camera Cable

16.4' (5m)

### Data Display

Frame Rate, Shutter Speed, Trigger Mode, Date or Time (can be switched), Status (Playback/Record), Real Time, Frame Count and Resolution

### Timing

Internal clock or external source such as IRIG or GPS (requires optional software module)

### Recording Modes

Start, End, Center, Manual, Random, Random Reset, Random Center, Random Manual and Dual Speed Recording™

### Partitioning

Dependent on memory configuration used; up to 48 partitions can be used

### Dimensions

**Camera Head:** (no lens mount) 4.72" (120mm) W x 4.72" (120mm) H x 4.19" (106.4mm) D

### Weight

3.5 lb (1.6 kg)

Specifications subject to change without notice